




1998-1999 Mitsubishi 3000GT, Dodge Stealth DOHC

Revised November 21, 2005

ECU Pinout Diagram

**Connector A (DOHC)**

Pin #	Name	Function	Signal Type
1	Injector 1	Injector Signal	Speed
2	Injector 2	Injector Signal	Speed
9	Injector 3	Injector Signal	Speed
10	Injector 4	Injector Signal	Speed
24	Injector 5	Injector Signal	Speed
25	Injector 6	Injector Signal	Speed

Connector B (DOHC)

Pin #	Name	Function	Signal Type
44	Water Temperature Sensor	Water Temperature Signal	Analog
45	Engine Ignition Signal	Engine Speed Signal (RPM)	Speed
46	ECM Ground	Chassis Ground	Ground
49	Ground for various sensors	Chassis Ground	Ground
51	Atmospheric Pressure Sensor	Atmospheric (Barometric) Pressure Sensor Signal	Analog
58	ECM Ground	Chassis Ground	Ground
61	Volume Air Flow Sensor	Mass Air Flow Sensor Signal	Analog
62	Air Intake Temperature Sensor	Air Intake Temperature Signal	Analog

Connector C (DOHC)

Pin #	Name	Function	Signal Type
71	O2 Sensor (Front)	Front Oxygen Sensor Signal	Analog
72	O2 Sensor (Front)	Front Oxygen Sensor Signal	Analog
73	O2 Sensor (Rear)	Rear Oxygen Sensor Signal	Analog
74	O2 Sensor (Rear)	Rear Oxygen Sensor Signal	Analog
78	Throttle Position Sensor	Primary Oxygen Sensor Signal	Analog
79	Closed Throttle Position Switch	Idle Position	Analog
80	Vehicle Speed Sensor	Vehicle Speed Sensor Signal	Speed
92	Manifold differential pressure sensor	MAP Sensor Signal	Analog
99	Ignition Switch	12V Switched	Power

Caution!

If you are not familiar with the vehicle's electrical systems, onboard sensors, and vehicle dynamics, DO NOT attempt to perform ANY installation of PLX Devices Inc. product(s). PLX Devices Inc. does not guarantee 100% accuracy, compatibility and specific application functionality of these documents. Use these documents as guidelines ONLY and refer to your vehicle's service manual for detailed information.